

AX1500G
MODELING SIGNAL PROCESSOR
REMS

[illegible]

1. Introduction	3
Main features	3
Printing conventions in this manual	3
Important things to learn	4
Front and rear panel	4
The modes of the AX1500G	7
Effect channels of the AX1500G	7
2. Playing the AX1500G	8
Example connections	8
Play mode	8
Adjusting the master level	8
Selecting a program	8
Switching between effect channels	9
Bypass and mute	9
Auto tuner	9
Metronome	9
Expression pedal	10
Individual mode	10
Phrase Trainer mode	11
3. Editing	12
Editing effects	12
Setting the noise reduction and program levels	13
Modifying program names	13
Writing programs	13
4. Appendices	14
Adjusting the expression pedal)	14
Restoring the user programs to the factory settings	14
Troubleshooting	15
Main specifications	15
Effect parameters	16
DRIVE-AMP effects block	16
CABINET effect block	17
MODULATION effect block	18
PEDAL effect block	20
AMBIENCE effect block	22
Preset Program List	23

KORG

Precautions

Location

Using the unit in the following locations can result in a malfunction.

- In direct sunlight
- Locations of extreme temperature or humidity
- Excessively dusty or dirty locations
- Locations of excessive vibration

Power supply

Please connect the designated AC adaptor to an AC outlet of the correct voltage. Do not connect it to an AC outlet of voltage other than that for which your unit is intended.

Interference with other electrical devices

This product contains a microcomputer. Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

Handling

To avoid breakage, do not apply excessive force to the switches or controls.

Care

If the exterior becomes dirty, wipe it with a clean, dry cloth. Do not use liquid cleaners such as benzene or thinner, or cleaning compounds or flammable polishes.

Keep this manual

After reading this manual, please keep it for later reference.

Keeping foreign matter out of your equipment

- Never set any container with liquid in it near this equipment. If liquid gets into the equipment, it could cause a breakdown, fire, or electrical shock.
- Be careful not to let metal objects get into the equipment. If something does slip into the equipment, unplug the AC adaptor from the wall outlet. Then contact your nearest Korg dealer or the store where the equipment was purchased.

THE FCC REGULATION WARNING (for U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Unauthorized changes or modification to this system can void the user's authority to operate this equipment.

CE mark for European Harmonized Standards

CE mark which is attached to our company's products of AC mains operated apparatus until December 31, 1996 means it conforms to EMC Directive (89/336/EEC) and CE mark Directive (93/68/EEC). And, CE mark which is attached after January 1, 1997 means it conforms to EMC Directive (89/336/EEC), CE mark Directive (93/68/EEC) and Low Voltage Directive (73/23/EEC).

Also, CE mark which is attached to our company's products of Battery operated apparatus means it conforms to EMC Directive (89/336/EEC) and CE mark Directive (93/68/EEC).

1. Introduction

Thank you for purchasing the **ToneWorks AX1500G Modeling Signal Processor**.

In order to enjoy your **AX1500G** to the fullest, please read this manual carefully, to ensure maximum performance. Please keep this manual for future reference.

Main features



- Korg's **REMS** modeling technology provides detailed and powerful modeling sounds.
- 56 types of modeling effect variations are built-in, and a maximum of eight types of effect can be used simultaneously.
- 48 preset programs (3 x 16 banks) and 48 rewritable user programs (3 x 16 banks) are built-in.
- You can switch between effect channels (A, B) to change the combination of the drive amp effect and the cabinet effect without switching programs.
- Use the effect block select knobs to instantly switch the effects for each of the five effect blocks (DRIVE-AMP, CABINET, MODULATION, PEDAL, AMBIENCE).
- You can use the expression pedal to control eleven types of pedal effects in realtime.
- In individual mode you can use foot switches to turn each effect on/off independently.
- The Sample & Play function lets you record a phrase that you play (for a maximum of 8 seconds), and then operate the pedal to play back the phrase.
- The built-in Phrase Trainer function lets you record sound from an audio device or a guitar performance (maximum 16 seconds), and play it back at a slower speed without changing the pitch.
- A metronome is built in for practicing convenience.
- Built in tuner mute function for on stage tuning.
- An AUX IN jack is provided so that you can play along with a connected audio device.
- Use the auto chromatic tuner to tune your instrument when the **AX1500G** is bypassed or muted.
- The LCD (liquid crystal display) features an intuitive visual interface.
- The LCD is backlit for easy visibility even in dark locations.

What is **REMS**?

REMS (Resonant structure and Electronic circuit Modeling System) is KORG's proprietary sound modeling technology which precisely reproduces the complex character and nature of both acoustic and electric instruments as well as electronic circuits in real world environments.

REMS emulates a wide variety of sound generation characteristics including instrument bodies, speakers & cabinets, acoustic fields, microphones, vacuum tubes, transistors, etc.

Printing conventions in this manual


The  logo indicates operating cautions, and  indicates useful advice.

LCD screens printed in this manual are only for purposes of illustration, and may not match the actual display on your **AX1500G**.

Important things to learn



Front and rear panel

Front panel



- ① **Effect select knobs**
These knobs select the effect model used in each effect block.
- ② **Effect block select switches**
(DRIVE-AMP, CABINET, MODULATION, PEDAL, AMBIENCE)
Press these switches to turn each effect block on/off or to edit it. The switch LED will be lit (on), dark (off), or blinking (edit).
- ③ **Value LEDs**
These LEDs will light to indicate the value knobs that can be used for the selected effect model. From the left, they correspond to value knobs 1—5.
- ④ **Value knobs**
When editing, rotate these knobs to modify the value of the parameter assigned to each knob. From the left, these are value knobs 1—5.
When not editing, these knobs control the parameters of the effect that is assigned to the DRIVE-AMP effect by the selected program. (Refer to p.12, “Quick editing for the DRIVE-AMP effect block.”)
- ⑤ **Effect channel switch, channel LED**
This changes the effect channel of the currently selected program. The LEDs located above the switch will light correspondingly (channel A is green, channel B is red).
- ⑥ **Program switches, program LEDs**
These switches select programs. The program LEDs (1, 2, 3) located above the switches will light correspondingly. In Individual mode, these switches turn each effect on/off individually.
- ⑦ **Bank switch**
Each time this switch is pressed, the bank number will increase by one. The bank number will decrease by one if you simultaneously press the bank switch and program switch 3.
- ⑧ **Expression pedal**
This pedal controls the effect that is selected from the PEDAL effect block.

LCD and control panel



- ① **Name display**
This shows the program name, effect name, or parameter name, as appropriate for each operation.
- ② **Edit icon**
This will light if the selected program has been edited. It will blink if the program is currently being edited.
- ③ **Phrase trainer icon**
This will blink when you are in **Phrase Trainer mode**.
- ④ **Metronome icon**
This will light when the metronome is on. It will blink while the metronome tempo or level is being adjusted.
- ⑤ **MASTER/VALUE display**
This shows the master level and parameter values. When the parameter value matches the value that is written in the program, the **ORIG** (original icon) will light.
- ⑥ **NR-PRG LEVEL switch**
Use this switch to adjust the amount of noise reduction or the level of each program.
- ⑦ **RENAME switch**
Use this switch to change the name of a program.
- ⑧ **Metronome LED**
This LED will blink in time with the metronome tempo.
- ⑨ **WRITE switch**
Use this switch to save an edited program.
- ⑩ **EXIT switch**
From any function, you can press this to return to **Play mode**.
- ⑪ **Cursor switches (◀, ▶)**
Use these switches to select the parameter that you wish to edit, or when modifying the name of a program.
- ⑫ **MASTER/VALUE switches (▲, ▼)**
Use these switches to change the master level or the value of a parameter.
- ⑬ **Pedal LED**
This indicates the on/off status and type of the pedal effect, and the recording status when the Sample & Play function is used.
- ⑭ **Bank number display**
This shows the bank number of the selected program. When a user program is selected, a decimal point "." located at the lower right of the bank number will light.

The modes of the AX1500G

The AX1500G has three modes: **Play mode**, **Individual mode**, and **Phrase Trainer mode**.


Play mode is the mode in which you can select a program and play it. When the power is first turned on, you will always be in this mode. You can select from a total of 96 programs that use high-quality effect models: 48 preset programs, and 48 user programs that allow you to freely edit the settings to create your own sounds. In addition, you can switch between effect channels A and B within each program.


With the factory settings, the user programs contain the same data as the preset programs.

Individual mode is the mode in which you can use the foot switches (the program switches and expression pedal switch) to individually turn each effect block on/off as you play. In this mode you can switch between effect channels A and B, but cannot switch between programs.

Use **Play mode** to select programs.

In **Phrase Trainer mode**, a phrase from an audio device (ie., CD or DAT) connected to the AUX IN jack or a guitar connected to the INPUT jack can be recorded and looped (played back repeatedly). You can practice by playing along with the repeating loop. As you can fix the pitch and slow down the playback speed, the phrase trainer mode is convenient for learning or practicing difficult phrases.

 When you enter this mode, the MODULATION, PEDAL, and AMBIENCE effect blocks will automatically be turned off. In this mode it is not possible to switch programs or effect channels.




In **Play mode** and **Individual mode**, you can use the effect select knobs etc. to edit the effects, adjust the noise reduction and program level, and modify the program name etc.

Effect channels of the AX1500G

The AX1500G provides an effect channel switch that lets you switch between two effect channels (A and B) within each program.


Each channel consists of a drive amp effect and a cabinet effect (see the diagram below).






This allows you to switch between rhythm and lead sounds within a single program as if you were changing the channel of a guitar amp, or to differentiate between sounds intended for direct output to a mixer using the cabinet effect or for output to your guitar amp.

2. Playing the AX1500G

Example connections

-  The power must be off when you make connections. Unintentional operation may damage your speakers, or cause malfunctions.

 - Connect your cables from the OUTPUT jacks of the **AX1500G** to your guitar amp or mixer etc.
If you are using a mono connection, connect the L/MONO jack. In order to take full advantage of the **AX1500G**'s sound, we recommend that you use stereo connections.
 - If you wish to use headphones, plug them into the PHONE jack.
-  The output from the OUTPUT jacks will be turned off when headphones are plugged in.
- Connect your guitar to the INPUT jack.
- If you wish to use the AUX IN jack, connect an external audio device to it. Use the controls of the connected device to adjust the volume.
- Connect the included AC adapter to the DC 9V jack, and plug the AC adapter into an AC outlet. When you plug it in, the power will come on automatically, and the name display will indicate the program name.
-  Wrap the AC adapter cable around the cable hook. When removing the cable from the hook, be careful not to pull the cable with excessive force.
- When you have finished making connections, turn on the power of your guitar amp or mixer etc. Play your guitar, and check whether connections have been made correctly. Adjust the master level of the **AX1500G** and the gain or fader controls of your guitar amp or mixer to set an appropriate volume level.





Play mode

When you turn on the power, the **AX1500G** will always enter **Play mode**, and will be set to the program and master level setting that were last selected when the power was turned off.



Adjusting the master level

The MASTER/VALUE display will show the master level immediately after the power is turned on, a program is selected, and after the **EXIT** switch is pressed.

When the master level is shown, you can use the **MASTER/VALUE** switches (, ) to adjust the master level.

Selecting a program

You can select from 48 preset programs and 48 user programs.

User and preset programs are each organized into 16 banks, with three programs in each bank. The currently selected bank is shown by the bank number display, and the program is shown by the program LEDs. To switch between user and preset programs, simultaneously press **MASTER/VALUE** switch () and cursor switch (). When a user program is selected, a decimal point "." located at the lower right of the bank number display will light.

User program

Preset program


To select a program in the same bank

Press a program switch 1—3 to select the desired program. The program LED of the selected program will light, and the name display will indicate the program name.

To select a program from a different bank

Press the bank switch to select the desired bank. (The bank number display will blink.) The banks will cycle in the order 0, 1, 2, ..., 9, A, b, C, d, E, F, 0, 1, 2...

- Each time you press the bank switch, the bank number display will increase by one.
- Each time you simultaneously press the bank switch and program switch 3, the bank number display will decrease by one.

When the desired bank number appears, press program switch 1, 2 or 3 to select the desired program. (The bank number display will change from blinking to lit.)

Checking the effect blocks used by a program

Not every program uses all of the effect blocks. When you select a program, the LED of each effect block that are used will light. The LEDs of effect blocks that are unused will be dark.

Switching between effect channels

Each time you press the effect channel switch, effect channels A and B will alternate. When channel A is selected, the channel LED is lit green, and when channel B is selected, the LED is lit red.

Effect channel hold

When you switch programs, this setting lets you specify whether the channel memorized in the program will be selected (OFF) or whether the status prior to switching programs will be maintained (On). The factory setting is OFF.

1. Press and hold the **EXIT** switch, and press the effect channel switch so that the name display indicates “**CH HOLD**” and the **MASTER/VALUE** display indicates “**OFF**” or “**On**”.
2. Continue holding the **EXIT** switch, and press the effect channel switch to change the setting between On and OFF.
3. Release the **EXIT** switch to return to **Play mode**.

Bypass and mute

Bypass

If you press and hold the program switch for 0.5 seconds, all effects will be bypassed. At this time, the program LED will blink, and the name display will indicate “**BYPASS**” for one second.

To defeat bypass, press the program switch whose LED is blinking, or press any other program switch.

Tips You can turn this on/off by simultaneously pressing **MASTER/VALUE** switch (▼) and cursor switch (◀). You can also turn it off by pressing the **EXIT** switch.

Mute

If you press and hold the program switch for 1.5 seconds or longer, the input sound (ie., guitar) from the **INPUT** will be muted. At this time, the program LED will blink more rapidly, and the name display will indicate “**MUTE**” for one second.

To defeat mute, press the program switch whose LED is blinking, or press any other program switch.

Tips This can be turned on by simultaneously holding **MASTER/VALUE** switch (▼) and cursor switch (◀) for one second, and off again by repeating this operation. It can also be turned off by pressing the **EXIT** switch.

Auto tuner

When the **AX1500G** is in bypass or mute, the tuner will operate automatically. If you mute the **AX1500G** you will be able to tune your instrument without producing sound. This is used for on stage tuning.


1. Tune your guitar so that the desired note name appears in the bank number display. The decimal point “.” at the lower right of the bank number display will light to indicate a sharp #.

Example display

A = A
d. = D#

2. Fine-tune your guitar so that only the center of the five value LED's is lit (or so that only the center of the name display is shown).

Tuning discrepancy shown by the value LED's and the name display



Changing the calibration setting


If necessary, you can adjust the calibration in the range of 438—445 Hz. (440 Hz is “standard”)

When the tuner is operating, use the **MASTER/VALUE** switches (▲, ▼) to adjust the setting. The calibration setting will appear in the **MASTER/VALUE** display.

⚠ When the power is turned off, the calibration setting you modify will be lost, and will automatically return to 440 Hz the next time the power is turned on.

Metronome

1. When you simultaneously press the **RENAME** and **EXIT** switches, the metronome will start and the metronome icon will blink.
2. Use value knob 4 to adjust the tempo (range 40—208: shown in the **MASTER/VALUE** display). At this time, the metronome LED will blink in time with the tempo.
3. Use value knob 5 to adjust the volume of the metronome (range 0—10: shown in the **MASTER/VALUE** display).
4. While the metronome is operating, simultaneously press the **RENAME** and **EXIT** switches to stop the metronome.



If you switch programs or edit while the metronome is operating, it will no longer be possible to adjust the tempo or level. To re-adjust the tempo or level, you must first stop the metronome, and then start it once again.

2. Playing the AX1500G

Tips As an alternative to using value knobs 4 and 5, you can use the cursor switches (◀, ▶) to switch parameters, and use the **MASTER/VALUE** switches (▲, ▼) to adjust the parameter values.

Tips While the metronome is operating, pressing the **EXIT** switch will stop the metronome and return to **Play mode**.

! When the **AX1500G** is bypassed or muted, it will not be possible to adjust the tempo or level.

Expression pedal

You can use the expression pedal for realtime control of eleven types of effects in the pedal effect block.

If the program uses an effect in the pedal effect block, the LED of pedal effect block will light.

The pedal LED will light yellow for **VOLUME** effect, green for a **VOX WAH--RING MOD** modulation-type effect, or red for a **HOLD DELAY--SAMPLE&PLAY** ambience-type effect.

For the **HOLD DELAY**, **TAP TEMPO DELAY**, and **SAMPLE & PLAY** pedal effects, the operation is different than for other effects (refer to p.21).

Using the expression pedal as you play

1. In **Play mode**, select a program that uses the expression pedal.
2. Make sure that the pedal LED is lit. If it is not lit, press the expression pedal firmly once to make the pedal LED light (the pedal will be turned on).
3. Operate the expression pedal while playing your guitar. As you raise and lower the pedal, the output sound will change correspondingly.

! If **Volume** is selected in the **PEDAL** effect block, it will not be possible to turn the expression pedal on/off. It will remain on (pedal LED lit yellow).

! The on/off status of the expression pedal is not memorized by each program.

! Do not apply excessive force to the expression pedal. Before operating the expression pedal, verify the amount of force that is required to make the pedal LED light and to apply the effect.

Individual mode

In this mode you can press the program switches and expression pedal switch to turn modulation, pedal, and ambience effect blocks on/off individually.

As in **Play mode**, you can switch the effect channel, and use operations such as metronome, editing, and program write.

! In this mode it is not possible to switch programs or to select bypass or mute.

Entering Individual mode


In **Play mode** press and hold the Bank switch for one second, and you will enter Individual mode. The name display will indicate “-INDIV-”, and the bank number display will indicate “≡.”

When you enter **Individual mode**, the program LED's will indicate the on/off status of each effect block (synchronized with the effect block LED's).

MODULATION corresponds to program switch (LED) 1, **AMBIENCE** to 2, **PEDAL** to 3.

Each time you press a program switch, it will turn on/off. For the pedal effect, pressing the expression pedal firmly will turn it on/off (the switch is located under the pedal). However for some pedal effects such as **SAMPLE & PLAY**, the expression pedal is used in a special way, and cannot be turned off once the pedal has been turned on.

! For some effects, it is not possible to simultaneously use the **MODULATION** and **PEDAL** effect blocks, or the **PEDAL** and **AMBIENCE** effect blocks. If you attempt to simultaneously turn on both of these effect blocks, the effect block that was turned on first will automatically be turned off.





Exiting Individual mode

To return to **Play mode**, press either the bank switch or the **EXIT** switch.

Phrase Trainer mode

You can record a phrase from an audio device (ie., CD or DAT) connected to the AUX IN jack or from a guitar connected to the INPUT jack, and loop it (i.e., play it back repeatedly). Then you can practice a phrase on your guitar while listening to the repeating phrase. Since you can slow down the playback speed without affecting the pitch, this is a convenient way to learn or practice phrases from recordings that are difficult to play. In **Phrase Trainer mode**, the effect expression pedal will automatically control the volume of the guitar.

 When you enter this mode, the MODULATION, PEDAL, and AMBIENCE effect blocks will automatically be turned off. (When you exit **Phrase Trainer mode**, the previous settings will be restored.)

 In this mode it is not possible to use Bypass or Mute, or to switch programs or effect channels.

1. Enter Phrase Trainer mode

From **Play mode**, simultaneously press and hold program switches 1 and 2 for one second. The MASTER/VALUE display will indicate the selected recording mode, and the Phrase Trainer icon will blink.

2. Select the recording mode

Use the cursor switches (◀, ▶) to select the input jack, and use the MASTER/VALUE switches (▲, ▼) to select the recording time.


Input jack "AUX" AUX IN jack
 "GTR" INPUT jack

Recording time "SHT" maximum 8 seconds (high quality)
 "LNG" maximum 16 seconds (extended time)

The phrase will be recorded and played back monaurally.


3. Begin recording


Start the audio device that is connected to the AX1500G, and press the bank switch (REC) at the point where you wish to begin recording. The name display will indicate "REC" and the number of seconds of recording.

 Once you record a phrase, it is not possible to change the recording mode. If you wish to change the recording mode, you must return to **Play mode**, and once again enter **Phrase Trainer mode**.

4. Stop recording

At the point where you wish to stop recording, press program switch 1 (▶/||) or the bank switch (REC). Recording will end, and the name display will indicate "PLAY." The recorded phrase will automatically begin playing repeatedly as a loop. Recording will also end automatically if you continue recording for the maximum time length of the selected recording mode.

 Depending on the volume of the connected audio device, the sound may be distorted. If this occurs, adjust the volume on the audio device.

 If the "AUX" input jack is used, the sound from the INPUT jack will be muted until recording ends.

To re-do the recording

Press program switch 1 (▶/||) to stop playback. Then continue with step "3. Begin recording" and step "4. Stop recording."

To erase the recorded phrase

The phrase will be erased when you press the EXIT switch to return to **Play mode**. You can also record a new phrase to overwrite the previously-recorded phrase.

5. Stop

When you press program switch 1 (▶/||), playback will stop. Press program switch 1 (▶/||) once again, and playback will resume from where you stopped.

- If effect channel switch (◀◀) is pressed while stopped, you will return to the beginning of the recorded phrase.
- By pressing the cursor switches, you can playback in reverse (◀) or forward (▶) as long as you hold down the switch.

6. Playback

During recording or while stopped, press program switch 1 (▶/||) to playback the recorded phrase as a repeating loop.

By pressing program switch 2 (SPEED) or the MASTER/VALUE switches (▲, ▼), you can slow down the playback speed without affecting the pitch.

- Each time you press program switch 2 (SPEED), the playback speed will cycle through settings of 100%, 75%, 50%, 25%...
- By pressing the MASTER/VALUE switches (▲, ▼), the speed can be adjusted in 5% steps; 100%, 95%, 90%, ... 25%.

During playback, you can press cursor switch (▶) to playback at double speed as long as you continue pressing the switch.

If you press cursor switch (◀), the recording will play back in reverse as long as you continue pressing the switch.


If you press effect channel switch (◀◀), the recording will rewind as long as you continue pressing the switch.

7. Hold

By pressing program switch 3 (HOLD), you can hold the sound that was playing at the moment the switch was pressed. When you press the switch once again, hold will be turned off. By pressing a cursor switch while the sound is being held, you can playback backward (◀) or forward (▶) as long as you continue holding the switch. If you press effect channel switch (◀◀), you will go back one second, cancel Hold, and begin playback.


Exiting Phrase Trainer mode

To return to **Play mode**, you can either press program switches 1 and 2 simultaneously, or press the EXIT switch.

 When you exit **Phrase Trainer mode** or turn off the power, the recorded phrase will be erased.

Setting the noise reduction and program levels

1. If you are in **Play mode**, press the **NR-PRG LEVEL** switch.
2. By rotating value knobs 1 or 2, or pressing the **NR-PRG LEVEL** switch, you can access the screen displays for adjusting the noise reduction and setting the level for each program.
3. To adjust the amount of noise reduction, use value knob 1 (range OFF...10: shown in the MASTER/VALUE display).
4. To adjust the level of each program, use value knob 2 (range 0...10: shown in the MASTER/VALUE display).



Tips Instead of value knobs 1 and 2, you can also use the cursor switches (◀, ▶) to select a parameter and use the **MASTER/VALUE** switches to adjust the value of the parameter.

Depending on the guitar that you use, raising the noise reduction setting too high may cause the sound to be cut off at low levels.

The volume of each program will change depending on the guitar that you use. Adjust the program level for your guitar.

If you wish to save the noise reduction and program level settings that you edited, you must perform the "Program write" operation. If you turn off the power or select a different program without writing the program, the program you modified will revert to its previous settings.

Tips You can also use the **MASTER/VALUE** switches to change the character.

If you wish to save the modified program name, you must perform the "Program write" operation. If you turn off the power or select a different program without writing the program, the program name you edited will revert to its previous setting.


Writing programs

Here's how to write an edited program.

1. Press the **WRITE** switch, and the name display will indicate "***WRITE***." The bank number display and the program LED will blink.
2. Use the **MASTER/VALUE** switches (▲, ▼) to select the writing destination bank, and use the cursor switches (◀, ▶) to select the writing destination program.
3. Press the **WRITE** switch once again, and the display will read "**COMPLT**" to indicate that the program has been written. You will then return to **Play mode**.


Tips You can also use value knob 5 or the bank switches to select the bank, and the program switches to select the program.

If you decide not to write, press the **EXIT** switch to cancel the Write operation.



Modifying program names

Press the **RENAME** switch and specify the program name (maximum 7 characters). Use the cursor switches (◀, ▶) to select the character that you wish to change (the character will blink). Then use value knob 5 to select the desired character. The available characters are shown below.



If you write an edited program to a different program number, the program that was overwritten will be lost.

It is not possible to write to a preset program.

Troubleshooting

If you suspect a malfunction, please check the following points first. If this does not resolve the problem, contact a nearby dealer.

1. Power does not turn on

- Is the AC adapter plugged into an AC outlet? (p.8)
- Is the included AC adapter connected? (p.6, 8)

2. No sound

- Are your guitar, amp, and headphones connected to the correct jack? (p.6, 8)
- Is the power of your amp turned on, and is it set accordingly?
- Is one of your cables broken?
- Is the master level of the **AX1500G** set to “0” or to a low value? (p.8)
- Is the program level of the **AX1500G** set to “0” or to a low value? (p.13)
- Is the **LEVEL** of the **DRIVE-AMP** effect set to “0” or to a low value? (p.12)
- Is the volume of your guitar turned down?
- Is the **AX1500G** muted?
- If **VOLUME** is selected for the **PEDAL** effect, has the pedal been returned to the full back position?

3. Effects are not applied

- Is the **AX1500G** bypassed? (p.9)
- Are the effects used by the program turned on? (p.4, 8)

4. Metronome does not function

- Are you in **Play mode** or in **Individual mode**?
The metronome will not function in **Phrase Trainer mode**.
- Is the metronome output level set to “0”? (p.9)


5. Pedal does not function

- Have you selected a program that uses an effect in the **PEDAL** effect block? (p.8)
- Is the pedal LED lit? (p.10)
- Try adjusting (calibrating) the expression pedal. (p.14)

6. Cannot write (the name display indicates “ERROR”)

- Reload the preset programs. (p.14)

Main specifications

- **Number of effects:**
56 types (maximum number of effects usable simultaneously: 8)
 - **Number of programs:**
96 (48 preset, 48 user)
 - **Inputs:**
Guitar input (mono phone jack)
AUX IN (stereo mini jack)
 - **Outputs:**
Output x 2 (mono phone jack)
Headphones (stereo mini jack)
 - **Tuner section**
Detection range:
27.5 Hz — 2,093 Hz (A0—C7)
Calibration:
A=438—445 Hz
 - **Metronome section**
Tempo:
bpm= 40—208
 - **Power supply:**
DC9V (included AC adapter )
 - **Dimensions:**
420 (W) x 187.7 (D) x 65.4 (H) mm
16.5 (W) x 7.4 (D) x 2.6 (H) inches
 - **Weight:**
2.4kg (5.3 lbs)
 - **Included items:**
Owner's manual, AC adapter
- * Specifications and appearance are subject to change without notice for improvement.

CABINET effect block

The shape of the cabinet and the type and number of speakers are very important elements in determining the tonal character of a guitar amp.

The CABINET effect block provides models that faithfully simulate the cabinet and speaker characteristics of a variety of guitar amps, from vintage to modern.

Although these models are especially effective when you are plugged in to a mixer etc. via a direct line connection, they are also effective when you are using a guitar amp.

CABINET	Knob 1 AIR	Knob 2 LEVEL	Knob 3 PRESENCE	Knob 4	Knob 5
1x8 TWEED	AP, 0.3...9.7, Ln	1...10	0...10		
1x12 TWEED	AP, 0.3...9.7, Ln	1...10	0...10		
1x12 BLACK PANEL	AP, 0.3...9.7, Ln	1...10	0...10		
1x12 AC15	AP, 0.3...9.7, Ln	1...10	0...10		
2x12 BLACK PANEL	AP, 0.3...9.7, Ln	1...10	0...10		
2x12 AC30	AP, 0.3...9.7, Ln	1...10	0...10		
2x12 CLASS A	AP, 0.3...9.7, Ln	1...10	0...10		
4x10 TWEED	AP, 0.3...9.7, Ln	1...10	0...10		
4x12 CLASSIC	AP, 0.3...9.7, Ln	1...10	0...10		
4x12 VINTAGE	AP, 0.3...9.7, Ln	1...10	0...10		
4x12 MODERN	AP, 0.3...9.7, Ln	1...10	0...10		

1x8 TWEED "1-8 TWD"

This model simulates an open back cabinet with one 8-inch speaker.

1x12 TWEED "1-12 TWD"

This model simulates an open back cabinet with one 12-inch speaker typically used for blues.

1x12 BLACK PANEL "1-12 BLK"

This model simulates an American open back cabinet with one 12-inch speaker and a bright tonal character.

1x12 AC15 "1-12AC15"

This model simulates a Vox open back cabinet with one 12-inch "Blue" speaker.

2x12 BLACK PANEL "2-12 BLK"

This model simulates an American open back cabinet with two 12-inch speakers.

2x12 AC30 "2-12AC30"

This model simulates a Vox open back cabinet with two 12-inch "Blue" speakers.

2x12 CLASS A "2-12 CLA"

This model simulates a modern open back cabinet with two 12-inch speakers.

4x10 TWEED "4-10 TWD"

This simulates an open back cabinet with four 10-inch speakers.

4x12 CLASSIC "4-12 CLS"

This simulates a closed back cabinet with four 25W 12-inch speakers.

4x12 VINTAGE "4-12 VIN"

This simulates a closed back cabinet with four 30W 12-inch speakers.

4x12 MODERN "4-12 MDN"

This simulates a closed back cabinet with four 75W 12-inch speakers.

Knob 1 AIR

This simulates the resonance of the cabinet, and the comb filtering effect produced by interference between the speakers.

Decreasing this value will produce a sound that is more suitable for connection to a guitar amp. Increasing this value will produce a sound that is more suitable for direct-line connection.

Knob 2 LEVEL Adjusts output level.

Knob 3 PRESENCE Adjusts tone of the high-frequency range.



If the sound distorts, slightly lower the **LEVEL** and **PRESENCE**.

MODULATION effect block

MODULATION	Knob 1 TIME	Knob 2 FEEDBACK	Knob 3 SPEED/PITCH	Knob 4 DEPTH/FINE	Knob 5 MIX/POLARITY
CLASSIC CHORUS	—	—	0.1...10[Hz]	0...10	1, 2
STEREO CHORUS	1...10	—	0.1...10[Hz]	0...10	—
CLASSIC FLANGER	1...10	0...10	0.1...10[Hz]	0...10	—
MOD DELAY	0.5...900[ms]	0...10	0.1...10[Hz]	0...10	0...10
BLACK PHASER	—	0...10	0.1...10[Hz]	—	—
ORANGE PHASER	—	0...10	0.1...10[Hz]	—	—
TEXTREM	—	—	1...10[Hz]	0...10	—
PITCH SHIFTER	0...900[ms]	0...10	-24...24[x100 CENT]	-15...15[CENT]	0...10
FILTRON	1...10	0...10	—	0...10	up, dn
AUTO WAH	1...10	—	—	0...10	up, dn
OCTAVE	—	—	—	0...10	0...10

Chorus, Flanger

Chorus and flanger are effects that delay the sound slightly to modulate the pitch, and combine the modulated sound with the original to produce a sensation of modulated spaciousness.

CLASSIC CHORUS "CL CHOR"

This simulates the very first vintage chorus unit. For the best results, use it in stereo.

Knob 3 SPEED	Adjusts speed.
Knob 4 DEPTH	Adjusts depth.
Knob 5 MIX	1: Use for mono output. 2: Use for stereo output.

STEREO CHORUS "ST CHOR"

This simulates a vintage stereo chorus unit that inverts the phase of the effect sound between left and right channels to make the sound more spacious. Adjusting the three knobs can produce a wide variety of results.

Knob 1	TIME	Adjusts delay time.
Knob 2	_____	_____
Knob 3	SPEED	Adjusts speed.
Knob 4	DEPTH	Adjusts depth. If this knob is placed in the "10" position, the TIME knob will have no effect.

CLASSIC FLANGER “CL FLAN”

This is a vintage flanger with rich tone. The settings can also be adjusted to produce chorus or vibrato-like effects.

Knob 1 TIME	Adjusts the delay time. This controls the bandwidth over which the effect is applied. As this setting approaches 0, modulation will occur at a higher pitch.
Knob 2 FEEDBACK	Adjusts the strength of the tonal character. To produce a jet airplane-like sound, increase to desired level.
Knob 3 SPEED	Adjusts speed.
Knob 4 DEPTH	Adjusts depth. If this knob is placed in the "10" position, the TIME knob will have no effect.

MOD DELAY "MOD DLY"

This effect modulates the delay time to produce chorus and flanger-like effects. Adding a small amount of depth with longer delay settings gives you a very effective modulated echo sound.

Knob 1	TIME	Adjusts delay time.
Knob 2	FEEDBACK	Adjusts feedback.
Knob 3	SPEED	Adjusts speed.
Knob 4	DEPTH	Adjusts depth.
Knob 5	MIX	Adjust the mix amount of effect sound.

Phaser

This effect cyclically modifies the phase shift of the sound, and mixes the phase-shifted sound with the original sound to produce modulation. The phased sound will become milder as the number of stages is increased.

BLACK PHASER "BL PHAS"

This is a popular four-stage vintage phaser.

ORANGE PHASER “OR PHAS”

This is a ten-stage vintage phaser that produces a milder effect.

Knob 2 **FEEDBACK** Adjusts the degree of character.
Knob 3 **SPEED** Adjusts the speed of modulation.

Tremolo

This modulates the volume to add depth to the sound.

TEXTREM	"TEXTREM"
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100

This effect model simulates the tremolo built into a guitar amp.

Knob 3	SPEED	Adjusts speed.
Knob 4	DEPTH	Adjusts depth.

Pitch shifter

This effect modifies the pitch.

PITCH SHIFTER "PITCH"

This pitch shifter can be adjusted over a ± 2 octave range.

- Knob 1 TIME Adjusts delay time.
- Knob 2 FEEDBACK Adjusts amount of feedback (delay repeats).
- Knob 3 PITCH Adjusts amount of pitch change.
- Knob 4 FINE Fine adjustment for the amount of pitch change.
- Knob 5 MIX Adjusts the mix amount of effect sound.

Auto wah

This is an auto-wah filter that automatically opens and closes according to the attack with which you play your guitar. The effect will vary depending on the guitars volume setting.

FILTRON "FILTRON"

This is a low-pass filter type auto-wah.

- Knob 1 TIME Adjusts the speed at which the wah will rise in response to your picking.
- Knob 2 FEEDBACK Adjusts the peak of the wah sound.
- Knob 3
- Knob 4 DEPTH Adjusts the sensitivity with which the wah will respond to your picking.
- Knob 5 POLARITY Specifies the direction in which the wah will operate.

AUTO WAH "AUTOWAH"

This is a band-pass filter type auto-wah that is equivalent to a pedal wah. It is placed before the DRIVE-AMP effect block.

- Knob 1 TIME Adjusts the speed at which the wah will rise in response to your picking.
- Knob 2
- Knob 3
- Knob 4 DEPTH Adjusts the sensitivity with which the wah will respond to your picking.
- Knob 5 POLARITY Specifies the direction in which the wah will operate.

Octave

This generates a pitch one octave lower than the original sound, and mixes it with the original sound to add a sense of depth and low end.



This effect may not operate correctly if two or more strings are played simultaneously, or when low-pitched strings are played.

OCTAVE "OCTAVE"

- Knob 4 DEPTH Adjusts the amount of the ultra-low pitch (one octave below).
- Knob 5 MIX Adjusts the amount of the original sound.

4. Appendices

PEDAL effect block

These effect models let you use the expression pedal to control the effect in realtime. They include a volume pedal, modulation-type effects such as **VOX WAH—RING MOD**, and ambience-type effects such as **HOLD DELAY—SAMPLE&PLAY**.



VOX WAH—RING MOD cannot be used simultaneously with the **MODULATION** effect block. Nor is it possible to use **HOLD DELAY—SAMPLE&PLAY** simultaneously with the **AMBIENCE** effect block.

PEDAL	Knob 1 TOP/TIME	Knob 2 FEEDBACK/ CENTER/REVERSE	Knob 3 BOTTOM/SPEED/ PITCH/TONE	Knob 4 DEPTH/FINE	Knob 5 LEVEL/MIX/ POLARITY
VOLUME	—	—	—	—	0...10
VOX WAH	—	—	—	—	—
TRAVELER	—	0...10	—	—	0...10
TALK	A, E, I, O, U	A, E, I, O, U	A, E, I, O, U	—	—
CHORUS/FLANGER	1...10	0...10	0.1...10	0...10	—
U-VIBE	—	—	—	0...10	1, 2
PITCH BEND	0...900[ms]	0...10	-24...24[x100 CENT]	-15...15[CENT]	0...10
RING MOD	—	—	1...10	—	—
HOLD DELAY	0[ms]...3[SEC]	0...10	1...10	—	0...10
TAP DELAY	0[ms]...3[SEC]	0...10	1...10	—	0...10
SAMPLE&PLAY	0.5...8[SEC]	OFF, 1, 2...8, LP1, LP2	—	—	0...10

Volume

This is a volume pedal.

VOLUME "VOLUME"

Knob 5 LEVEL Adjust the minimum level for when the pedal is in the full back position.

Pedal wah, Traveler, Talking pedal

These are wah (filter) effects that use the pedal to control the frequency response.



If you use this effect in a program where the MODULATION effect block is turned on, the MODULATION effect block will automatically be turned off.

VOX WAH "WAH"

This simulates a vintage wah pedal. There are no adjustable parameters. It is placed ahead of the DRIVE-AMP effect block.

TRAVELER	"TRAVEL"
1. <i>Traveler</i> (1999)	1. <i>Travel</i> (1999)
2. <i>Traveler</i> (2001)	2. <i>Travel</i> (2001)
3. <i>Traveler</i> (2003)	3. <i>Travel</i> (2003)
4. <i>Traveler</i> (2005)	4. <i>Travel</i> (2005)
5. <i>Traveler</i> (2007)	5. <i>Travel</i> (2007)
6. <i>Traveler</i> (2009)	6. <i>Travel</i> (2009)
7. <i>Traveler</i> (2011)	7. <i>Travel</i> (2011)
8. <i>Traveler</i> (2013)	8. <i>Travel</i> (2013)
9. <i>Traveler</i> (2015)	9. <i>Travel</i> (2015)
10. <i>Traveler</i> (2017)	10. <i>Travel</i> (2017)
11. <i>Traveler</i> (2019)	11. <i>Travel</i> (2019)
12. <i>Traveler</i> (2021)	12. <i>Travel</i> (2021)
13. <i>Traveler</i> (2023)	13. <i>Travel</i> (2023)
14. <i>Traveler</i> (2025)	14. <i>Travel</i> (2025)
15. <i>Traveler</i> (2027)	15. <i>Travel</i> (2027)
16. <i>Traveler</i> (2029)	16. <i>Travel</i> (2029)
17. <i>Traveler</i> (2031)	17. <i>Travel</i> (2031)
18. <i>Traveler</i> (2033)	18. <i>Travel</i> (2033)
19. <i>Traveler</i> (2035)	19. <i>Travel</i> (2035)
20. <i>Traveler</i> (2037)	20. <i>Travel</i> (2037)
21. <i>Traveler</i> (2039)	21. <i>Travel</i> (2039)
22. <i>Traveler</i> (2041)	22. <i>Travel</i> (2041)
23. <i>Traveler</i> (2043)	23. <i>Travel</i> (2043)
24. <i>Traveler</i> (2045)	24. <i>Travel</i> (2045)
25. <i>Traveler</i> (2047)	25. <i>Travel</i> (2047)
26. <i>Traveler</i> (2049)	26. <i>Travel</i> (2049)
27. <i>Traveler</i> (2051)	27. <i>Travel</i> (2051)
28. <i>Traveler</i> (2053)	28. <i>Travel</i> (2053)
29. <i>Traveler</i> (2055)	29. <i>Travel</i> (2055)
30. <i>Traveler</i> (2057)	30. <i>Travel</i> (2057)
31. <i>Traveler</i> (2059)	31. <i>Travel</i> (2059)
32. <i>Traveler</i> (2061)	32. <i>Travel</i> (2061)
33. <i>Traveler</i> (2063)	33. <i>Travel</i> (2063)
34. <i>Traveler</i> (2065)	34. <i>Travel</i> (2065)
35. <i>Traveler</i> (2067)	35. <i>Travel</i> (2067)
36. <i>Traveler</i> (2069)	36. <i>Travel</i> (2069)
37. <i>Traveler</i> (2071)	37. <i>Travel</i> (2071)
38. <i>Traveler</i> (2073)	38. <i>Travel</i> (2073)
39. <i>Traveler</i> (2075)	39. <i>Travel</i> (2075)
40. <i>Traveler</i> (2077)	40. <i>Travel</i> (2077)
41. <i>Traveler</i> (2079)	41. <i>Travel</i> (2079)
42. <i>Traveler</i> (2081)	42. <i>Travel</i> (2081)
43. <i>Traveler</i> (2083)	43. <i>Travel</i> (2083)
44. <i>Traveler</i> (2085)	44. <i>Travel</i> (2085)
45. <i>Traveler</i> (2087)	45. <i>Travel</i> (2087)
46. <i>Traveler</i> (2089)	46. <i>Travel</i> (2089)
47. <i>Traveler</i> (2091)	47. <i>Travel</i> (2091)
48. <i>Traveler</i> (2093)	48. <i>Travel</i> (2093)
49. <i>Traveler</i> (2095)	49. <i>Travel</i> (2095)
50. <i>Traveler</i> (2097)	50. <i>Travel</i> (2097)
51. <i>Traveler</i> (2099)	51. <i>Travel</i> (2099)
52. <i>Traveler</i> (2101)	52. <i>Travel</i> (2101)
53. <i>Traveler</i> (2103)	53. <i>Travel</i> (2103)
54. <i>Traveler</i> (2105)	54. <i>Travel</i> (2105)
55. <i>Traveler</i> (2107)	55. <i>Travel</i> (2107)
56. <i>Traveler</i> (2109)	56. <i>Travel</i> (2109)
57. <i>Traveler</i> (2111)	57. <i>Travel</i> (2111)
58. <i>Traveler</i> (2113)	58. <i>Travel</i> (2113)
59. <i>Traveler</i> (2115)	59. <i>Travel</i> (2115)
60. <i>Traveler</i> (2117)	60. <i>Travel</i> (2117)
61. <i>Traveler</i> (2119)	61. <i>Travel</i> (2119)
62. <i>Traveler</i> (2121)	62. <i>Travel</i> (2121)
63. <i>Traveler</i> (2123)	63. <i>Travel</i> (2123)
64. <i>Traveler</i> (2125)	64. <i>Travel</i> (2125)
65. <i>Traveler</i> (2127)	65. <i>Travel</i> (2127)
66. <i>Traveler</i> (2129)	66. <i>Travel</i> (2129)
67. <i>Traveler</i> (2131)	67. <i>Travel</i> (2131)
68. <i>Traveler</i> (2133)	68. <i>Travel</i> (2133)
69. <i>Traveler</i> (2135)	69. <i>Travel</i> (2135)
70. <i>Traveler</i> (2137)	70. <i>Travel</i> (2137)
71. <i>Traveler</i> (2139)	71. <i>Travel</i> (2139)
72. <i>Traveler</i> (2141)	72. <i>Travel</i> (2141)
73. <i>Traveler</i> (2143)	73. <i>Travel</i> (2143)
74. <i>Traveler</i> (2145)	74. <i>Travel</i> (2145)
75. <i>Traveler</i> (2147)	75. <i>Travel</i> (2147)
76. <i>Traveler</i> (2149)	76. <i>Travel</i> (2149)
77. <i>Traveler</i> (2151)	77. <i>Travel</i> (2151)
78. <i>Traveler</i> (2153)	78. <i>Travel</i> (2153)
79. <i>Traveler</i> (2155)	79. <i>Travel</i> (2155)
80. <i>Traveler</i> (2157)	80. <i>Travel</i> (2157)
81. <i>Traveler</i> (2159)	81. <i>Travel</i> (2159)
82. <i>Traveler</i> (2161)</	

This is a low-pass filter type wah modeled after a vintage Korg effect pedal.

Knob 1 _____

Knob 2 FEEDBACK Adjusts the peak amount of the filter.

Knob 3 _____

Knob 4 _____

Knob 5 LEVEL Adjusts the output level.

TALK "TALK"

This adds vocal type effects to your guitar.

Knob 1 TOP Select the vowel sound produced when
the pedal is fully forward.

Knob 2 CENTER Select the vowel sound produced when the pedal is in the halfway position.

Knob 3 BOTTOM Select the vowel sound produced when the pedal is fully backward.

* Vowel sounds — A. E. I. O. U

Chorus/Flanger

This is a chorus/flanger effect that uses the pedal to control the mix amount of the effect.



If you use this effect in a program where the MODULATION effect block is on, the MODULATION effect block will automatically be turned off.

CHORUS/FLANGER "CH/FLAN"

Knob 1 TIME Adjusts delay time.

Knob 2 FEEDBACK Adjusts amount of feedback (delay repeats).

Knob 3 SPEED Adjusts pitch modulation speed.

Knob 4 DEPTH Adjusts pitch modulation depth.

U-Vibe

This simulates a vintage vibrato/rotary speaker simulator.



If you use this effect in a program where the MODULATION effect block is on, the MODULATION effect block will automatically be turned off.

U-VIBE “U-VIBE”

Knob 4 DEPTH Adjusts depth of the effect.

Knob 5 MODE

- 0:** Mixes the original sound with the effected sound (Chorus mode)
- 1:** Output only the effect sound (Vibrato mode)

Pitch bend

This is a Pitch shifter that uses the pedal to control the pitch.



If you use this effect in a program where the MODULATION effect block is on, the MODULATION effect block will automatically be turned off.

PITCH BEND "P BEND"

- Knob 1 **TIME** Adjusts the delay time.
- Knob 2 **FEEDBACK** Adjusts the amount of feedback (delay repeats).
- Knob 3 **PITCH** Adjusts the amount of pitch change.
- Knob 4 **FINE** Make fine adjustments to the amount of pitch change.
- Knob 5 **MIX** Adjusts the mix amount of the effect. With a setting of 10, only the effect sound will be heard in the output.

Ring modulator

This effect multiplies the original sound with a sine wave to produce bell-like effects. The cleanest results will be produced if you use the neck pickup of your guitar, turn down the tone, and pluck the string near the twelfth fret.



If you use this effect in a program where the MODULATION effect block is on, the MODULATION effect block will automatically be turned off.

RING MOD "RINGMOD"

This is a ring modulator that lets you use the pedal to control the frequency.

- Knob 3 **PITCH** Adjusts the tone when the pedal is advanced.

Delay

These effects mix a time-delayed sound with the original sound to add depth and spaciousness to the sound.



If you use this effect in a program where the AMBIENCE effect block is on, the AMBIENCE effect block will automatically be turned off.

HOLD DELAY "HOLDLY"

This will normally function as a delay, but when the pedal is advanced all the way forward to press the switch, the pedal LED will blink and the sound will be held (the delay sound will continue to be heard). Since you can use the pedal to control the input level to the delay, you can easily produce special effects such as sound-on-sound. In Individual mode, you can also hold by pressing program switch 2.

TAP DELAY "TAP DLY"

When you advance the pedal forward and press the switch twice, the tap tempo delay function will apply a delay at the corresponding tempo. The pedal LED will temporarily go dark the instant that the switch is pressed. The depth to which the pedal is pressed will control the input level to the delay. In Individual mode, you can also press program switch 2 twice to specify the tempo.

- Knob 1 **TIME** Adjusts the delay time.
- Knob 2 **FEEDBACK** Adjusts the feedback amount (delay repeats).
- Knob 3 **TOPE** Adjusts the tone of the effect sound.
- Knob 4 _____
- Knob 5 **MIX** Adjusts the mix amount of the effect sound.

Sample and play



If you use this effect in a program where the AMBIENCE effect block is on, the AMBIENCE effect block will automatically be turned off.

SAMPLE&PLAY "S+PLAY"

This allows approximately 8 seconds of recording. By using the reverse setting, you can produce special "scratch" effects.

1. Press the expression pedal all the way forward to enter record-ready mode. The pedal LED will blink. In **Individual mode**, press program switch 2 to enter record-ready mode.
2. Play a phrase etc. on your guitar. Recording will begin automatically at the moment you start playing and the pedal LED will begin blinking faster.
3. When the recording time specified by **TIME** has elapsed, recording will end and the pedal LED will not be lit. Also, you can stop recording before the specified recording time has elapsed by pressing the pedal all the way forward (i.e., pressing the pedal switch). To re-do the recording, repeat the procedure from step 1.



During recording, you can also return the pedal and then press it again to stop recording and begin playback.

4. Operate the expression pedal. When you advance the pedal, the recorded phrase will playback. If you have set **REVERSE** to **A-1...A-4** or **b-1...b-4**, returning the pedal will cause the sound to playback in reverse at the specified speed. If you set **REVERSE** to **OFF**, the sound will only playback forward. With a setting of **LP1** or **LP2**, advancing the pedal forward will playback the sound as a repeating loop. When you return the pedal back and then advance the pedal again, playback will begin from the beginning.



Recording will not begin unless you play your guitar louder than the threshold.



The recording sound will be erased when you enter Phrase Trainer mode or when you turn off the power.

- Knob 1 **TIME** Specifies the sample time (recording time).
- Knob 2 **REVERSE** **OFF**: When you press the pedal, the sound will playback to the end and then stop.

LP1: Press the pedal forward to playback as a loop, and return the pedal backward to stop.

LP2: Press the pedal forward to playback as a loop, and return the pedal backward to playback to the end and then stop.

A-1...A-4: Press the pedal forward to playback, and return the pedal backward to playback in reverse.

b-1...b-4: Press the pedal forward to playback from the beginning, and return the pedal backward to playback in reverse from the end.

- Knob 3 _____
- Knob 4 _____
- Knob 5 **MIX** Adjusts the output level of the sampled sound.

4. Appendices

AMBIENCE effect block

These are reverberation-type effect models such as delay, reverb, and echo.

AMBIENCE	Knob 1 TIME	Knob 2 FEEDBACK	Knob 3 TONE	Knob 4 ECHO	Knob 5 MIX/REVERB
ECHO PLUS	60[mS]...3[SEC]	0...10	1...10	—	0...10
MULTI HEAD ECHO	180[mS]...3[SEC]	0...10	1...10	1, 2, 3, 4, 5	0...10
STEREO DELAY	0[mS]...3[SEC]	0...10	1...10	—	0...10
PING PONG DELAY	0[mS]...3[SEC]	0...10	1...10	—	0...10
ROOM	1...10	—	1...10	—	0...10
HALL	1...10	—	1...10	—	0...10
PLATE	1...10	—	1...10	—	0...10
SPRING	1...10	—	1...10	—	0...10
ECHO+ROOM	0[mS]...2[SEC]	0...10	1...10	0...10	0...10
ECHO+HALL	0[mS]...2[SEC]	0...10	1...10	0...10	0...10
ECHO+PLATE	0[mS]...2[SEC]	0...10	1...10	0...10	0...10

Tape echo simulator

This effect model simulates the characteristic tape echo effect produced by recording sound on analog magnetic tape and playing it back from a playback head located at a slight distance from the recording head.





ECHO PLUS "ECHO+"

This simulates a tape echo. Pitch discrepancies produced by unevenness in the rotational speed, and the distortion and loss of audio quality due to the magnetic tape are also simulated.

Knob 1	TIME	Adjusts the delay time.
Knob 2	FEEDBACK	Adjusts the feedback amount (delay repeats).
Knob 3	TONE	Adjusts the tonal quality of the echo.
Knob 4	_____	_____
Knob 5	MIX	Adjusts the mix amount of the echo.

MULTI HEAD ECHO “MH ECHO”

This simulates a tape echo with four playback heads. The distortion and loss of audio quality due to the magnetic tape are also simulated.

Knob 1	TIME	Adjusts the delay time.
Knob 2	FEEDBACK	Adjusts the feedback amount (delay repeats).
Knob 3	TONE	Adjusts the tonal quality of the echo.
Knob 4	ECHO	1: Conventional echo.
		2:  The delayed sound produces a rhythm of "ta-ta-ta (rest)."
		3:  The delayed sound produces a rhythm of "ta (rest) ta-ta."
		4:  The delayed sound produces a rhythm of "ta-ta (rest) ta."
		5:  The delayed sound produces a rhythm of "ta-ta-ta-ta."
Knob 5	MIX	Adjusts the mix amount of the echo.

Delay

STEREO DELAY "ST DLY"

A stereo delay with a time difference between the left and right channels adds a spacious feeling.

PING-PONG DELAY "PP DLY"

This is a stereo delay where the sound bounces between the left and right channels.

Knob 1	TIME	Adjusts the delay time.
Knob 2	FEEDBACK	Adjusts the feedback amount (delay repeats).
Knob 3	TONE	Adjusts the tonal quality of the delay.
Knob 4	_____	_____
Knob 5	MIX	Adjusts the mix amount of the delay.

Reverb

This effect model simulates the reverberation of a room or concert hall, or the reverberation produced by a plate or spring reverb device.

ROOM	"ROOM"
101	101
102	102
103	103
104	104
105	105
106	106
107	107
108	108
109	109
110	110
111	111
112	112
113	113
114	114
115	115
116	116
117	117
118	118
119	119
120	120
121	121
122	122
123	123
124	124
125	125
126	126
127	127
128	128
129	129
130	130
131	131
132	132
133	133
134	134
135	135
136	136
137	137
138	138
139	139
140	140
141	141
142	142
143	143
144	144
145	145
146	146
147	147
148	148
149	149
150	150
151	151
152	152
153	153
154	154
155	155
156	156
157	157
158	158
159	159
160	160
161	161
162	162
163	163
164	164
165	165
166	166
167	167
168	168
169	169
170	170
171	171
172	172
173	173
174	174
175	175
176	176
177	177
178	178
179	179
180	180
181	181
182	182
183	183
184	184
185	185
186	186
187	187
188	188
189	189
190	190
191	191
192	192
193	193
194	194
195	195
196	196
197	197
198	198
199	199
200	200

This simulates the reverb of small studio-sized rooms to medium-sized rooms such as a garage.

HALL "HALL"

This simulates the reverberation of medium-sized halls to large halls.

PLATE	"PLATE"
This simulates a plate reverb device.	

SPRING	"SPRING"
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100

This effect model simulates the spring reverb devices built into guitar amps etc.

Knob 1 TIME Adjusts the length of reverb.

Knob 2 _____

Knob 3 TONE Adjusts the tone of the reverb.

Knob 4 _____

Knob 5 MIX Adjusts the mix amount of the reverb.

ECHO+ROOM “ECHO RM”

DUAL ROOM. **DUAL RM.**
This is a dual effect model that lets you simultaneously use both a room reverb and a stereo delay.

ECHO+HALL “ECHO HL”

This is a dual effect model that lets you simultaneously use both a hall reverb and a stereo delay.

ECHO+PLATE “ECHO PL”

This is a dual effect model that lets you simultaneously use both a plate reverb and a stereo delay.

Knob 1 TIME Adjusts the delay time.

Knob 2 FEEDBACK Adjusts the feedback amount (delay repeats).

Knob 3 TONE Adjusts the tone of the delay sound.

Knob 4 ECHO Adjusts the mix amount of the delay sound.

Knob 5 REVERB Adjusts the mix amount of the reverb.

Preset Program List

When an effect block that was off is turned on, the effect model printed in a slanted typeface will be selected.

A cabinet model appropriate for each program is selected in the CABINET effect block. If you will be using a direct output connection to a mixer etc., you should turn on the CABINET effect block.

BANK#	PROGRAM	A (DRIVE-AMP • CABINET)	B (DRIVE-AMP • CABINET)	MODULATION	PEDAL	AMBIENCE
0	1 ONE	CLASSIC COMP • 2x12 BLACK PANEL	METAL DIST • 4x12 VINTAGE	STEREO CHORUS	VOLUME	HALL
	2 FRUITLP	TUBE OD • 1x12 AC15	BRIT STACK • 4x12 CLASSIC	MOD DELAY	SAMPLE&PLAY	SPRING
	3 VULGAR	BRIT STACK • 4x12 VINTAGE	BRIT STACK • 4x12 VINTAGE	PITCH SHIFTER	VOLUME	HALL
1	1 ACUSTIX	ACOUSTIC • 4x12 CLASSIC	TUBE OD • 4x10 TWEED	CLASSIC CHORUS	VOLUME	PING PONG DELEY
	2 LOVEGUN	BRIT STACK • 4x12 VINTAGE	BRIT STACK • 4x12 VINTAGE	CLASSIC CHORUS	PITCH BEND	HALL
	3 GRUNGY	BIG FUZZ • 4x12 MODERN	BIG FUZZ • 4x12 MODERN	CLASSIC FLANGER	VOLUME	SPRING
2	1 SUMMER	CLASSIC COMP • 1x12 BLACK PANEL	TUBE OD • 4x12 MODERN	STEREO CHORUS	TAP TEMPO DELAY	STEREO DELEY
	2 "STP"	US HI-GAIN • 4x12 VINTAGE	US HI-GAIN • 4x12 VINTAGE	MOD DELAY	VOLUME	ROOM
	3 GRINDER	BRIT STACK • 4x12 MODERN	BRIT STACK • 4x12 MODERN	PITCH SHIFTER	VOLUME	HALL
3	1 MARATHN	CLASSIC COMP • 4x12 MODERN	ACOUSTIC • 4x12 VINTAGE	STEREO CHORUS	CHORUS/FLANGER	ECHO+PLATE
	2 STONE	BRIT STACK • 1x12 BLACK PANEL	BRIT STACK • 4x12 CLASSIC	MOD DELAY	VOLUME	PLATE
	3 *ZEP*	ACOUSTIC • 4x12 VINTAGE	METAL DIST • 4x12 VINTAGE	STEREO CHORUS	VOLUME	ECHO PLUS
4	1 ROOSTER	CLASSIC COMP • 4x12 CLASSIC	SEATTLE • 4x12 MODERN	AUTO WAH	VOX WAH	ECHO PLUS
	2 BEETLE	TOP BOOST • 1x12 AC15	TUBE OD • 4x12 VINTAGE	BLACK PHASER	VOLUME	ROOM
	3 BECKOLA	CLASSIC DIST • 1x12 BLACK PANEL	FAT DIST • 4x12 CLASSIC	CLASSIC CHORUS	TALK	MULTI HEAD ECHO
5	1 L-A	CLASSIC COMP • 1x12 BLACK PANEL	TUBE OD • 1x12 AC15	MOD DELAY	VOLUME	SPRING
	2 LODRIVE	FAT DIST • 4x12 VINTAGE	FAT DIST • 4x12 MODERN	ORANGE PHASER	VOLUME	STEREO DELEY
	3 AXPRNCE	TOP BOOST • 2x12 AC30	BIG FUZZ • 2x12 AC30	AUTO WAH	VOLUME	PLATE
6	1 PET-CLN	ACOUSTIC • 1x12 BLACK PANEL	CLASSIC COMP • 1x12 BLACK PANEL	STEREO CHORUS	VOLUME	ECHO+PLATE
	2 BLUES	CLASSIC COMP • 4x10 TWEED	TOP BOOST • 1x8 TWEED	STEREO CHORUS	VOLUME	ROOM
	3 IMAGES	CLASSIC COMP • 4x10 TWEED	METAL DIST • 4x12 CLASSIC	AUTO WAH	VOX WAH	PLATE
7	1 LP NECK	CLASSIC COMP • 2x12 AC30	US HI-GAIN • 2x12 AC30	CLASSIC CHORUS	VOLUME	PING PONG DELEY
	2 TRIPPIN	CLASSIC COMP • 4x10 TWEED	TUBE OD • 4x10 TWEED	ORANGE PHASER	VOLUME	ECHO PLUS
	3 RHYTHM	CLASSIC COMP • 1x12 TWEED	METAL DIST • 4x12 MODERN	BLACK PHASER	TAP TEMPO DELAY	ECHO PLUS
8	1 FATSRAT	TUBE OD • 2x12 BLACK PANEL	BRIT STACK • 4x12 CLASSIC	MOD DELAY	VOLUME	ROOM
	2 HIDDEN	CLASSIC COMP • 4x12 MODERN	CLASSIC DIST • 2x12 AC30	FILTRON	TRAVELER	PING PONG DELEY
	3 OCTAMAN	TOP BOOST • 4x12 VINTAGE	SEATTLE • 4x12 VINTAGE	OCTAVE	VOLUME	ECHO+PLATE
9	1 INDABOX	BIG FUZZ • 1x8 TWEED	FAT DIST • 1x8 TWEED	MOD DELAY	TALK	ROOM
	2 U-VIBE	CLASSIC COMP • 4x12 VINTAGE	FAT DIST • 4x12 VINTAGE	ORANGE PHASER	U-VIBE	PLATE
	3 BENDER	US HI-GAIN • 4x12 MODERN	METAL DIST • 4x12 MODERN	PITCH SHIFTER	PITCH BEND	SPRING
A	1 FILTRON	CLASSIC COMP • 4x12 VINTAGE	US HI-GAIN • 1x12 AC15	FILTRON	VOLUME	STEREO DELEY
	2 BARITON	CLASSIC COMP • 2x12 CLASS A	TUBE OD • 4x12 CLASSIC	TEXTREM	VOLUME	ECHO+PLATE
	3 CHORUS	CLASSIC COMP • 2x12 BLACK PANEL	FAT DIST • 4x12 CLASSIC	CLASSIC CHORUS	VOLUME	PLATE
B	1 S+P LP	CLASSIC COMP • 4x10 TWEED	US HI-GAIN • 4x12 CLASSIC	CLASSIC FLANGER	SAMPLE&PLAY	ECHO+HALL
	2 S+P SLW	TOP BOOST • 2x12 AC30	BRIT STACK • 4x12 CLASSIC	MOD DELAY	SAMPLE&PLAY	PLATE
	3 S+P FST	TUBE OD • 4x12 MODERN	US HI-GAIN • 2x12 BLACK PANEL	STEREO CHORUS	SAMPLE&PLAY	MULTI HEAD ECHO
C	1 HOLDDLY	CLASSIC COMP • 4x12 VINTAGE	US HI-GAIN • 4x12 MODERN	STEREO CHORUS	HOLD DELAY	STEREO DELEY
	2 TAP DLY	TUBE OD • 1x12 BLACK PANEL	CLASSIC DIST • 4x12 CLASSIC	CLASSIC CHORUS	TAP TEMPO DELAY	PLATE
	3 3-HEAD-	TOP BOOST • 1x8 TWEED	BIG FUZZ • 2x12 BLACK PANEL	ORANGE PHASER	VOLUME	MULTI HEAD ECHO
D	1 TWEED	TUBE OD • 2x12 BLACK PANEL	CLASSIC DIST • 1x12 TWEED	MOD DELAY	VOLUME	ECHO+HALL
	2 60'SVOX	TOP BOOST • 2x12 AC30	TOP BOOST • 2x12 AC30	TEXTREM	VOLUME	ROOM
	3 BRITISH	BRIT STACK • 4x12 VINTAGE	BRIT STACK • 4x12 VINTAGE	AUTO WAH	VOX WAH	ECHO+PLATE
E	1 CREED	ACOUSTIC • 1x8 TWEED	CLASSIC DIST • 4x12 CLASSIC	STEREO CHORUS	VOLUME	PLATE
	2 STK-LN	BRIT STACK • 4x12 CLASSIC	BRIT STACK • 4x12 VINTAGE	BLACK PHASER	VOLUME	SPRING
	3 PP-DLY	TOP BOOST • 2x12 AC30	US HI-GAIN • 4x12 MODERN	CLASSIC CHORUS	CHORUS/FLANGER	PING PONG DELEY
F	1 CLN-LN	CLASSIC COMP • 2x12 CLASS A	TOP BOOST • 2x12 AC30	MOD DELAY	VOLUME	HALL
	2 "VH"	BRIT STACK • 4x12 CLASSIC	BRIT STACK • 4x12 VINTAGE	CLASSIC FLANGER	CHORUS/FLANGER	MULTI HEAD ECHO
	3 7-STGTR	US HI-GAIN • 4x12 MODERN	US HI-GAIN • 4x12 MODERN	STEREO CHORUS	VOLUME	ECHO+HALL

NOTICE

KORG products are manufactured under strict specifications and voltages required by each country. These products are warranted by the KORG distributor only in each country. Any KORG product not sold with a warranty card or carrying a serial number disqualifies the product sold from the manufacturer's/distributor's warranty and liability. This requirement is for your own protection and safety.